

The ATTAS[®] -Operating columns

The ATTAS[®] operating columns are ideally suited for the installation of entry and exit controls, such as key switches, code keys, magnetic card readers, intercom systems, and many more.

Due to the lockable doors / maintenance flaps, optionally on the front or on the back, you can conveniently wire the access controls.

The operating columns are available in different sizes, either for cars only, for trucks only or for both.

Sizes (W x D x H):

- ST1 PKW (150 x 120 x 1.150 mm)
- ST2 PKW (270 x 250 x 1.150 mm)
- ST2 PKW/LKW (270 x 250 x 2.000 mm)
- ST3 PKW (370 x 350 x 1.150 mm)
- ST3 PKW/LKW (370 x 350 x 2.000 mm)

Variants:

- Doors / maintenance flaps on the front side
- Doors / maintenance flaps on the rear side

Material and Colours:


- Brushed stainless steel
- Stainless steel powder coated
- > possible in all RAL colours

Operating Columns




Examples


ST1 PKW




ST2 PKW



ST3 PKW



ST3 PKW/LKW



ATTAS GmbH

Automatische Tür und Tor Antriebs Systeme

Boschstraße 25 71336 Waiblingen

Tel. 07151 / 36 902-0 FAX 07151 / 36 902-190

Email info@attas.de Internet <http://www.attas.de>